

SOKKIA SET B MANUAL

Table of Contents

1. INTRODUCTION	3
1.1. SYMBOLOGY	4
1.2. CONFIGURATIONS	6
1.3. LEVELING THE INSTRUMENT.....	11
1.4. CHECK THE TILT SENSORS	14
2. FIELDWORK	16
2.1. ANGLE MEASUREMENT.....	16
2.1.1. Setting the horizontal circle to zero	16
2.1.2. Inputting a known azimuth	16
2.2. SIDE SHOTS OR DISTANCE READING.....	17
2.2.1. Setting the prism offset and atmospheric correction.....	17
2.2.2. Slope, Horizontal or Vertical Difference of Height.....	18
2.2.3. Coordinate measurement.....	19
2.3. SAG CHECKS ON POWERLINES (REMOTE ELEVATION)	21
2.4. MISSING LINE MEASUREMENT	21
2.5. STAKE-OUT	22
2.5.1. Inputting stake-out values	22
2.5.1.1. Angle & Distance stake-out.....	22
2.5.1.2. Coordinate stake-out.....	22
2.5.2. Setting out stake-out values	23
2.5.2.1. Angle & Distance stake-out.....	23
2.5.2.2. Coordinate stake-out.....	23

3. USING THE ON-BOARD DATA COLLECTOR (“C” SERIES)	24
3.1. DATA COLLECTION OPTIONS.....	24
3.2. ERASING OR FORMATTING THE CARD	25
3.3. STARTING A NEW JOB	26
3.5. USING THE CODE STACK FEATURE	27
3.6. REVIEWING YOUR DATA.....	28
4. TROUBLESHOOTING AND ERROR MESSAGES	29

1. Introduction

This Total Station Training Manual is intended to help you understand and get the most out of the Sokkia Total Station that you have chosen. This training manual is not intended to replace the instrument manual that you received with your total station. However, this training manual should be used to help you get up and running much quicker than you might normally would.

How to use this training manual

To get the best results from this manual, you should read it cover to cover once, then setup your instrument and go through the functions of the instrument using this manual as your tour guide.


At the beginning of each section a Resource Box will precede the written directions. The Resource Box will tell you before hand what buttons on the instrument that you will be using during this particular procedure and where in the instrument manual to find additional information about that function of the instrument.

We've tried to make this Total Station Training Manual as user-friendly as possible. If you have any suggestions or comments please submit them to:











Sokkia Corporation
Training Center
9111 Barton
Overland Park, Kansas 66214

1.1. Symbology

The following symbols represents the icons found on the SET2, 3, 4, BII and CII series total stations. Please make yourself very familiar with the following icons. This will help you learn your total station much quicker than usual.



LETTER	DEFINITION
A	Recalls last distance or NEZ reading or enters a negative number
B	Slope distance or number 7
C	Horizontal distance or number 8
D	Vertical difference in height or number 9
E	Light key
F	Decimal point or Setting out
G	Calculate a coordinate or number 4
H	Remote elevation or number 5
I	Missing line measurement or number 6
J	Clear entry
K	Card reader or number 0
L	Menu key (Configuration, Coordinate entry) or number 1
N	Programs key (Resection, Correction and Pt. replace) or number 2
M	Theodolite mode or number 3
O	Enter key or Shift mode


EDM A	 B	 C	 D	 E
 F	 G	f / m H	 I	No J
0 SET K	 L	 M	 N	Yes O

Letter	Function
A	Change the E.D.M. mode. (Fine, Coarse, Tracking)
B	Enter theodolite height
C	Enter target height
D	Offset (Angle or Distance)
E	E.D.M. signal strength
F	Coordinate entry (Station, BS, Stake-out point)
G	Entry of stake-out distance and/or angle
H	Changes distance display to feet or meters for 6 seconds
I	Calculate BS azimuth
J	No
K	Set the horizontal angle to zero
L	Input a known horizontal angle
M	Hold the horizontal angle
N	Horizontal angle right, left, or repetition of angle
O	Yes

1.2. Configurations

This is one of the most important sections in these manual. The configuration of your instrument is vital to your productivity. When you learn how to configure your instrument to the way you survey, you will benefit by getting the most out of your instrument.

Depress the MENU key and select number 1, Config.

- 
- 1. Config
 - 2. Card
 - 3. Code

The follow screen snaps will appear when you are in the Configuration Menu by pressing the up or down arrow keys. When you want to change the settings on the screen, press the "ENTER" key.



If you are using a 'C' series instrument, you have the ability to input coordinates for staking out from either the data card on board the instrument or by hand input. If you are using a "B" series instrument the only chose you have is to hand enter the coordinates.



When using a "C" series instrument, you can specify if you want to send the data to the card or send it to an external device. You can specify weather or not to input a code, also weather or not to input a target height.




This allows you to turn on your dual axis compensation by selecting YES or turn off the dual axis compensation by selecting NO.




This screen allows you to specify how you will enter your coordinate data, Northing-Easting-Elevation or Easting-Northing-Elevation.



This sets your vertical angle to read from Zenith or Horizontal 0°–360° or Horizontal +/- 90°.



This sets the minimum display angle. If you are using a 2BII, 2CII, 3BII, 3CII your choice is 1" or 5" increments. If you are using a 4BII or 4CII your choice is 5" or 10" increments.



When using an external device (other than an SDR-33) this allows you to set the communication parameters. Baud rate (1200-2400), Checksum (Yes or No), Parity bit (No or Yes-even).



When you first turn on your instrument, you have to index both the vertical circle and the horizontal circles. By selecting "Auto"

the instrument will orientate the vertical circle to 90°. If you select "Manual", you will have to collimate your instrument vertically ever


time you turn your instrument on. Selecting "Manual" is not recommended.



Much like the Vertical Indexing, the Horizontal Indexing (when the instrument is turned on) needs the instrument to rotated 360° horizontally. When the Horizontal Indexing is set to "Auto" the instrument will remember where the horizontal circle is set to Zero, ever after the instrument is turned off. When the Horizontal Indexing is set to "Manual" the instrument will not have to be rotated 360° after it is turned on.



If you would like to have the instrument automatically correct for the Earth's curvature and refraction (C + R). You will have three choices; No, Yes K=0.142, Yes K=0.20. In the United States most surveyors will select Yes K=0.142.



This allows you to setup your units of measurement. Feet or meters for distance measuring, Degrees or Gons for angle measurement, or the temperature and pressure settings. You can set the PPM in °C & mbar, °C & mmHg, °F & mbar, °F & mmHg or °F & inches Hg.



If the instrument is left untouched for 30 minutes, the instrument will turn itself off. You can also select for the instrument not to turn itself off by choosing "Power On/Off by key operation".



By selecting “Key On/Off by key operation” the backlight is completely controlled by you. When you need the backlight on, press the light key. When you want to turn it off, depress the light key again. Or select “30 second time-out” so the light will automatically turn itself off after 30 seconds.



When Audio for return signal is On, the instrument will hum when it acquired a prism. This only works when you depress the



This screen will allow you to set the intensity of the reticle illumination to either bright or dim.



This is a quick way to configure your instrument. This will set the instruments parameters back to the original factory settings. The following table is a listing of the factor settings.

Screen order	Parameter	Factory default setting
1	Coordinate data from	Keyboard
2	Recording	Out, Code, Target ht.
3	Tilt correction	Yes
4	Coordinate format	N, E, Z
5	V angle format	Zenith
6	Angle resolution	1" (5")
7	RS232C format	1200

Screen order	Parameter	Factory default
8	V indexing	Auto
9	H indexing	Auto
10	C+R correction	No
11	Units	M, D, C & mbar
12	Auto power off	30min timeout
13	Backlight control	Key on/off
14	Audio for return signal	On
15	Reticle illumination	Bright
16	Config Default set	

After you have become familiar with the configuration parameters, make sure you set the parameters for the way you survey.

1.3. *Leveling the instrument*

Setting up the instrument

Mount the battery in the instrument before performing this operation, because the instrument will tilt slightly if the battery is mounted after leveling.

Set up the tripod

- 1) Make sure the tripod legs are spaced at equal intervals and the head is approximately level.
- 2) Set the tripod so that the head is positioned over the surveying point.
- 3) Make sure the tripod shoes are firmly fixed in the ground.

Install the instrument

- 4) Place the instrument on the tripod head.
- 5) Supporting it with one hand, tighten the centering screw on the bottom of the unit to make sure it is secured to the tripod.

Focus on the surveying point


- 6) Looking through the optical plummet eyepiece, turn the optical plummet eyepiece to focus on the reticle.
- 7) Turn the optical plummet focusing ring to focus on the surveying point.

Leveling

Center the surveying point in the reticle

- 8) Adjust the leveling foot screws to center the surveying point in the optical plummet reticle.


Center the bubble in the circular level



- 9) Observe the off-center direction of the bubble in the circular level, and shorten the nearest tripod leg, or extend the leg farthest from that direction to center the bubble.
- 10) One more tripod leg must be adjusted to center the bubble.

Center the bubble in the plate level

- 11) Loosen the horizontal clamp to turn the upper part of the instrument until the plate level is parallel to a line between leveling screws A and B.



Turn 90° and center the bubble




- 12) Turn the upper part of the instrument through 90°. The plate level is now perpendicular to a line between leveling screws A and B.
- 13) Center the air bubble, using leveling screws

Turn another 90° and check bubble position




- 14) Turn the upper part of the instrument a further 90° and check to see if the bubble is in the center of the plate level. If the bubble is off-center, perform the following:
 1. Adjust leveling screws A and B in equal and opposite directions, to remove half of the bubble displacement.
 2. Turn the upper part a further 90°, and use leveling screw C to remove half of the displacement in this direction.

1.4. Check the tilt sensors

Due to the fact that your total station uses dual axis compensation for better accuracy, it is important that you check the adjustment of the tilt sensors for time to time. This procedure is highly recommended and only takes a couple minutes.

When adjusting the tilt sensors, you will use the theodolite key  , the SHFT key  , and the zero set key  .

Turn the instrument on, level it and index the circles.


- At the theodolite screen  , press the theodolite key  . The display will change to the "Tilt sensor" screen  . In a field book record the X and Y value. (Be sure to note whether the value is a positive or negative number)
- Rotate the instrument 180° (let the instrument settle for 10 to 15 seconds) and record the X and Y values. (Be sure to note whether the value is a positive or negative number)
- The values that you have recorded should be directly opposite of each other. For example:

Observation face	X Value	Y Value
Face 1 X	0°00'35"	
Face 1 Y		0°01'10"
Face 2 X	-0°00'35"	
Face 2 Y		-0°01'00"
X difference	0°00'00"	

Y difference		0°00'10"
--------------	--	----------

- Using the above table as an example, the X axis is right on and the Y axis is 10" off. Because we read the tilt sensors in both the Face 1 and Face 2 positions, you should divide the results by 2. Thus, $X=0" / 2 = 0"$, $Y=10" / 2 = 5"$. We have no error in the X axis and 5" of error in the Y axis. The tilt sensors should be within the stated accuracy of your instrument. For instance, using the above example, if you have a SET4BII or SET4CII, the stated accuracy is 5" so the tilt sensor is in adjustment.

If the X and/or Y results are out of adjustment

- Begin at the tilt sensor screen and press the SHFT  Yes

and zero set keys  . The display will change to

Tilt angle	
Take F1	
HAR	#####"

- Turn the instrument 180° horizontally, let the instrument settle for 10 to 15 seconds

2. Fieldwork

This section of the training manual is intended to aid you in actual field work situations.

2.1. *Angle measurement*

This section will cover most of the theodolite functions of your SET.

2.1.1. Setting the horizontal circle to zero



After you have set up your instrument, typically you will observe your backsight. A good habit to get into is Zero setting the horizontal circle to read zero on your backsight. To accomplish this turn the instrument and aim at the backsight.

Press the  Shift key and then the  0 set key.

The display will change the horizontal angle to zero.

2.1.2. Inputting a known azimuth



If a need arises to input a known backsight azimuth this can be done very easy.


Press the  Shift key and then the  angle input key. Now, input the known horizontal angle, e.g. 45°10'15", you will type 45.1015 and then enter.


2.2. Side shots or distance reading

2.2.1. Setting the prism offset and atmospheric correction

If you have a need to set the atmospheric correction the SET makes it very easy on you. The only information you will input is the current temperature and barometric pressure. To


input the values press the  shift key and the  EDM key.

The display will change to , select number 3. You can choose just to set the ppm values to zero or input your values for your ppm. In this example choose number 2, input ppm. At this point input the temperature and pressure and press Enter. Look at the operators window on the SET and you will see a ppm value.

E.g. 



To set your prism constant you follow the same process as setting your ppm, except press 2. Your display will change to



. At this point just type in your prism constant. A typical value is -30. Now, just press Enter and Clear to return to the main menu.


2.2.2. Slope, Horizontal or Vertical Difference of Height

When you are ready to take a distance reading simple aim the instrument at your prism and depress the appropriate distance key, i.e. slope, horizontal, or vertical difference in height.



If you chose to take a slope distance reading and really needed a horizontal distance, don't worry you have two options. Obviously you can retake the shot pressing the horizontal distance key, however if the rod person has moved already



you can press the  recall key and then press whatever distance key you want to review.

When the SET takes a distance reading it solves for all of the distances and a coordinate. So by pressing the recall key you can recall any of the distances you might need.


2.2.3. Coordinate measurement


The SETB's, SETC's and SET5A have the capability of calculating a coordinate value based from an azimuth and station coordinates that you have entered. The following is a typical flow for coordinate measurements.


Inputting Station Coordinates

Press the  Shift key and the  coordinate input key.

- | | |
|----|-----------|
| 1. | Station |
| 2. | Backsight |
| 3. | S-O point |

The display will change to . The press the number 1 key to select Station and input the


display will change to . The N


will flash. Input 1000.00 and press the  Enter key. The E will flash, input 1000.00 and press the Enter key. The Z will flash, input 150.00 and press the Enter key.

You have just entered your station point coordinates.


If you know your backsight coordinates, press number 2 "BACKSIGHT" and follow the same procedures as above to enter your backsight coordinates. For this example enter in;

N	1500.00
E	1500.00
Z	125.00

After you enter the Z value and press Enter, press the  No

 Clear key to go to the main menu. Now aim the instrument at your backsight target, lock down your tangents.

Now you should calculate your backsight azimuth. This is done



by pressing the **ENT/SHIFT** and **6** Calculate BS azimuth key. This uses the coordinate values you've entered to calculate the azimuth from the station to the backsight and change the horizontal angle display to that azimuth. Once you press the Calculate BS key the display will change to the theodolite screen. For this example the display will change

ZA	92° 27'45"
HAR	45° 00'00"

to **4**. Now aim the instrument at a




sideshot target and press **4** coordinate measurement key. The instrument will display the coordinate value of any sideshot you take.

REMEMBER

After you take a coordinate measurement you can recall the Slope, Horizontal and/or Vertical Difference of height.

2.3. *Sag checks on powerlines (Remote elevation)*


This routine will require taking two measurements. The first that you desire to get a verticle height on. The next reading will be with the  Remote Elevation key which will cause the instrument to beep continuously and if you move the verticle axis up or down

Ht	24.65ft
ZA	69° 59' 22"
HAR	62° 18' 02"


you will notice the Ht change vaules which are your clearance or depth values. In this routine the target height is very important since the heights are dependent upon a correct target height.

2.4. *Missing line measurement*

This routine also require two measurments and can be used in two ways. The first will be if you want to receive a radial distances from a single point. Take your normal reading to the first point (or your fixed point). The second shot will be to the point(s) that you wish to measure to, when taking this shot you will use

the  Missing Line key which will in turn take another reading to the point. You may continue to use this routine as an inversing routine to several points from the first, your only concern is that you only use the Missing Line key to take a reading.

The other option for this key is if you want to measure distances between one point and on to the next then you will need to take a regular distance to the first

point for the system to know what you are measuring from and then the  Missing line key, then take a regular reading so the base now becomes the last shot and so on and so forth, keep reading points this way.

Remember: Each reading in this routine needs a prism.


2.5. Stake-out

2.5.1. Inputting stake-out values

2.5.1.1. Angle & Distance stake-out


While entering data for Angle and Distance stake-out you will press the  Yes





Shift key and  Stake-Out data key. The display will change to

S-O data	
D.	125.00ft
HAR	292° 12' 00"



and the D. will be flashing allowing you to enter the

Yes
distance, then press  enter to move to the horizontal angle and now HAR should be flashing and you can enter in your horizontal angle and then press

Yes
 Enter to accept this entry.

Remember: If at any time during entry of this data you can press the  No
Clear key to erase an entry if you haven't already accepted it.

2.5.1.2. Coordinate stake-out

To enter a coordinate for stake-out you will push the  Yes Shift and  Yes
Stake-Out key to get to the coordinate menu, which will give you the following

1.	Station
2.	Backsight
3.	S-O point



display. Press the number 3 key for S-O point data which will then take you into a coordinate entry option similar to regular coordinate entry (section 2.2.3). The N will flash for your entry of that value and so on.

You now have values entered for a Stake-out point.

2.5.2. Setting out stake-out values


2.5.2.1. Angle & Distance stake-out




To go through the angle & distance is done in two steps. First you will turn the

angle to be set out by selecting the  Stake-Out Key and the  Horizontal angle key. which will give you a screen that looks like the following:

Delta to angle for stake-out	dHA	-16° 39' 30"
Current Horizontal Angle	HAR	69° 12' 24"

The top number will count down to zero and the bottom number will eventually read the exact angle you entered as the stake-out angle. The next phase of this

stake-out is the distance. At this point again you select the  Stake-Out

Key and then the appropriate distance type, either ,  or,  depending upon what you entered to be staked out, typically the distance will be a horizontal distance.

2.5.2.2. Coordinate stake-out

The steps needed to stake out a coordinate are as follows:

Press the Stake-Out Key and then the Coordinate measuring Key and at this point you will get values that show you how far you are from the intended point. The values mean as follows:

N	15.05	This value being positive means move to the North 15.05 feet.
E	-23.78	This value being negative means to move to the West 23.78 feet.
Z	-6.51	This value being negative means that there is a 6.51 foot cut.

The values only update on each reading to a prism.

3. Using the on-board data collector ("C" Series)

3.1. Data collection options



O SET



The data collection options are found after selecting the Record Key, they are listed as follows:

- S,V,H Slope distance, Verticle angle, Horizontal angle
- S,V,H (offset) Slope, verticle, horizontal, with an offset
- V,H, Tilt Verticle angle, Horizontal angle, tilt correction readings
- N,E,Z coordinates - North, East, & Elevation
- N,E,Z + S, V, H Both coordinates - North, East, & Elevation & Slope distance, Verticle angle, Horizontal angle
- Note Alpha-numeric information
- Station data Date, Station ID, Code, Intrument Ht, Temp, Pressure, C&R Correction, Prism constant, Tilt on or off, and Coordinates (North, East & Elevation)
- Instr ID Instrument type and Serial Number

The following screen will show you an example of the recording screen.



EDM



To scroll throught the options use the Recall key and the



Yes

Stake-Out key. To select one of the options for a reading press the



Yes

No

Key and to exit press the





No Key.


Card Menu Options

The card menu options are found by selecting the Menu Key and then pressing the 2 Key for Card, they are listed as follows:

- Job/file Creating, selecting, or deleting a job
- format Formats the card
- write protect turns write protect on or enables card
- data read
- data write
- data output
- comms communicate with computer software


3.2. Erasing or formatting the card


If using a new card you must format it. To do so press the  Menu Key and then select the 2 Key for Card operations, then you must use either the  RCL


Recall Key to move up in the stack or  Stake-Out to move down in the stack to the format option, as shown below.

◆ Card format Yes / No (exit)	Formatting ok? Yes / No (exit)	Start ? Yes => press "1" Exit => press "No"
-------------------------------------	-----------------------------------	---

You can now press the 1 Key to begin the formatting process and then the message displayed will say Format end.

To erase a job from the card you begin by pressing the  Menu Key and then select the 2 Key for Card operations. Then you will need to scroll through

the options to get to the following screen: , then press

the  Yes key to go into that option and then the following screen will be

displayed

1. create
2. select
3. delete

. Now press the 3 Key to go into the

delete options. You will then see the next screen

◆ Job / file name DEMO Yes / No (exit)
--

which allows you to scroll through the jobs on the card using the

EDM ./+ RCL

 and

Yes ENT SHFT

 to get to the Job that you want to delete and then press the

Yes ENT SHFT

 Yes key when you are sure that you have selected the one you want to delete.

3.3. Starting a new job

To start a new job on the card you begin by pressing the

◆ 1 MENU

 Menu Key and then select the 2 Key for Card operations. Then you will need to scroll through

the options to get to the following screen:

◆ Card Job / file Yes / No (exit)

, then press

the

Yes ENT SHFT

 Yes key to go into that option and then the following screen will be

displayed

1. create
2. select
3. delete

. Now press the 1 Key to create a new job.

You will then see the next screen







◆ press Job ABCDEFGHIJ 0123456789

 and you will notice that the word "Job" flashes to prompt for the input of a Job name. To get to more letters of the alphabet you may need to press the Recall Key and the Stake-Out Key to scroll through the options.



3.4. Using the code stack feature


In using this option you can store a list of features in a stack that can be recalled when taking a shot and entering a code. The operations available for feature code entry are as follows:


- view allows you to view the current list of codes in a stack
- card => stack moves a feature code file from the card to the memory stack of the instrument
- card <= stack moves a feature code stack from the memory stack of the instrument to a file on the card
- stack + allows you to add feature codes to the stack
- stack - allows you to delete a feature code from the stack


To get into the above options you need to select the  Menu Key and then press the  Key for Code operations. You will use the  Recall Key and the  Stake-Out Key to move through the options available. You will see the next screen displayed, , to select the option you want press the  Yes Key.


3.5. Reviewing your data

To view the data stored on the card you first press the  Recall Key and then the  Record Key, which displays the following screen,







If the job that shows up is the correct one that you want to review then press the  Yes Key. If it is not the job that you want


press the  No Key which will then give you the following screen,







to allow you to scroll through a list of jobs available.

Once you have the job you want press the  Yes Key, which will give you

the following screen, . Now you may use the  Recall Key and the  Stake-Out Key to scroll through the data available to viewing. Once you get to a point that you want to see detailed data about press

the  Yes Key and you will receive the following screen(s):

4. Troubleshooting and error messages

Error codes showing up on the instruments are as follows:

All errors in the 100 range are angle reading errors (ie 110 - Horizontal Signal out of working range)

Even numbers are Horizontal
Odd numbers are Vertical

EDM errors are in the 200 range, (ie 205 - Power to EDM not sufficient)

If powering on unit that has not been used for a period of time show error, you may just turn the unit off and back on again to clear up the error.

Many of the errors are caused by a low power signal.